


Octopus F100/200/400/650
Octopus F IP-Netpackage
Octophon F615 TDM

Operating Instructions



Important information



Never open the telephone or a key module. Should you encounter any problems, contact the responsible service personnel.

Use only original accessories. The use of other accessories may be hazardous and will render the warranty, extended manufacturer's liability and the CE marking invalid.

Trademarks



The device conforms to the EU directive 1999/5/EC as attested by the CE marking.



All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.

Proper disposal and separate collection of your old appliance will help prevent potential damage to the environment and human health. It is a prerequisite for reuse and recycling of used electrical and electronic equipment.

For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service, the shop where you purchased the product or your sales representative.

The statements quoted above are only fully valid for equipment which is installed and sold in the countries of the European Union and is covered by the directive 2002/96/EC. Countries outside the European Union may impose other regulations regarding the disposal of electrical and electronic equipment.

Location of the telephone

- The telephone should be operated in a controlled environment with an ambient temperature between 5°C and 40°C.
- To ensure good speakerphone quality, the area in front of the microphone (front right) should be kept clear. The optimum speakerphone distance is 50 cm.
- Do not install the telephone in a room where large quantities of dust accumulate; this can considerably reduce the service life of the telephone.
- Do not expose the telephone to direct sunlight or any other source of heat, as this is liable to damage the electronic components and the plastic casing.
- Do not operate the telephone in damp environments, such as bathrooms.

Documentation

These operating instructions can be found on CD-ROM (ask the service personnel) in HTML and PDF format.

To view or print the operating manual in PDF format, you need a computer on which the free Adobe Acrobat Reader program is installed.

To view the operating manual in HTML format, you need a computer with a Web browser, for example, Microsoft Internet Explorer.

Contents

Important information 2

Trademarks	2
Location of the telephone	3
Documentation	3

General information..... 10

About this manual	10
Service	10
Intended use	11
Telephone type	11
Speakerphone quality and display legibility	11
Multi-line telephone, executive/secretary functions.	11
Team functions	11

Getting to know your Octophon phone 12

The user interface of your Octophon F615 TDM	12
key module for Octophon F615	13
Keys	14
Audio keys	14
Mailbox key and Menu key	14
Navigation keys	14
Programmable function keys	15
Keypad	16
Display	17
Idle mode	17
Mailbox	18
Messages	18
Voicemail	18
Caller list	19
Program/Service menu	20

Basic functions	21
Answering a call	21
Answering a call via the handset	21
Answering a call via the loudspeaker (speakerphone mode)	22
Switching to speakerphone mode	23
Switching to the handset	23
Open listening in the room during a call	23
Making calls	24
Off-hook dialing	24
On-hook dialing	24
Dialing with DDS keys	24
Redialing a number	25
Ending a call	25
Reject calls	26
Turning the microphone on and off	26
Calling a second party (consultation)	27
Switching to the held party (alternating)	27
Transferring a call	28
Call forwarding	29
Using variable call forwarding	29
Using call forwarding no reply (CFNR)	30
Call forwarding in the carrier network and forwarding multiple subscriber numbers (MSN)	31
Using callback	32
Storing a callback	32
Accepting a callback	32
Viewing and deleting a stored callback	33

Enhanced phone functions	34
Answering calls	34
Accepting a specific call for your colleague	34
Using the speakerphone	35
Answering calls from the entrance telephone and opening the door	36
Accepting a call from an answering machine	37
Making calls	38
En-bloc sending/correcting numbers	38
Using the caller list	39
Dialing a number from the internal directory	40
Using the LDAP directory	41
Making calls using system speed-dial numbers	43
Dialing with speed-dial keys	43
Talking to your colleague with a speaker call	44
Talking to your colleague with discreet calling	45
Automatic connection setup (hotline)	45
Reserving a trunk	45
Assigning a station number	46
Associated dialing/dialing aid	46
During a call	47
Using call waiting (second call)	47
Preventing and allowing call waiting (automatic camp-on)	48
Turning the call waiting tone on and off	48
Saving a number	48
Parking a call	49
Holding external calls	50
Conducting a conference	51
Activating tone dialing/DTMF suffix-dialing	53
Recording a call	54
Transferring a call after a speaker call announcement in a group	55
Send trunk flash	56
If you cannot reach a destination	57
Call waiting (camp-on)	57
Busy override – joining a call in progress	57
Using night answer	58
Programming the function keys	59
Configuring function keys	59
Overview of functions	60
Programming a procedure key	62
Configuring redial keys	64
Deleting function key programming	65

Displaying and assigning call charges 66

Displaying call charges 66
 Displaying call charges for another telephone 67
 Dialing with call charge assignment 68

Privacy/security 69

Turning ringer cutoff on and off 69
 Activating/deactivating "Do not disturb" 70
 Caller ID suppression 71
 Silent Monitoring/Secret busy override 71
 Monitoring a room 72
 Trace call: identifying anonymous callers 72
 Locking the telephone to prevent unauthorized use 73
 Locking another telephone to prevent unauthorized use 74
 Saving your PIN 75

More functions/services. 76

Appointments function 76
 Saving appointments 76
 Using timed reminders 77
 Sending a message 77
 Creating and sending a message 77
 Viewing and editing incoming messages 78
 Leaving an advisory message 79
 Deleting advisory messages 79
 Displaying the number of waiting calls/overload display 80
 Using another telephone like your own for a call 80
 Change number (exchanged phone/move/relocate) 81
 Fax details and message on answering machine 81
 Resetting services and functions (system-wide cancellation for a telephone) 82
 Activating functions for another telephone. 83
 Using system functions from outside DISA (direct inward system access) 84
 Using functions in ISDN via code dialing (keypad dialing) 85
 Controlling connected computers/programs/telephone data service 86
 Communicating with PC applications over a CSTA interface. 87
 Controlling relays 88
 Sensors (Octopus F200/F400 only) 88
 Paging persons 89

Making calls in the team/executive/ secretary configuration. 90

Lines	90
Line utilization	90
Line seizure	90
Trunk keys	91
Answering calls with the trunk keys	92
Dialing with trunk keys	92
Placing a call on hold on a trunk key and retrieving the held call	92
Making calls on multiple lines alternately	93
MULAP conference release	93
Direct station selection key	94
Using DSS keys to answer calls	94
Calling a team member directly	94
Transferring a call in progress	95
Accepting a call for another team member	95
Forwarding calls on trunks	96
Transferring calls directly to the executive phone	98

Using team functions. 99

Activating/deactivating a group call	99
Accepting a call for another member of your team	101
Ringing group	101
Uniform Call Distribution (UCD)	102

Special functions in the LAN 104

Leaving hunt group/group call	104
Setting up "follow me" call forwarding	105
Using night answer	106
Ringing group	107
Controlling relays (only for Octopus F100/200/400/650)	108
Opening a door	109

Individual phone configuration 110

Setting contrast	110
Adjusting audio settings	110
Adjusting the receiving volume during a call	110
Adjusting the ring volume	110
Adjusting the ring tone	111
Adjusting the attention ring volume	111
Adjusting the speakerphone to the room acoustics	111
Activating/deactivating the ringer	112
Language for system functions	112

Testing the phone	113
Phone functions, testing	113
Checking the key assignment	113
Differing display view in a Octopus F900 environment.....	114
Fixing problems.....	115
Responding to error messages	115
Contact partner in the case of problems	115
Troubleshooting	116
Caring for your telephone	116
Labeling keys	117
Index.....	118
Overview of functions and codes.....	123

General information

About this manual


This document contains general descriptions of the technical options, which may not always be available in individual cases. The respective features must therefore be individually defined in the terms of the contract.

If a particular function on your phone is not available to you, this may be due to one of the following reasons:

- The function is not configured for you or your telephone. Please contact your system support representative.
- Your communications platform does not feature this function. Please contact your service personnel for information on how to upgrade.

This user guide is intended to help you familiarize yourself with Octophon and all of its functions. It contains important information on the safe and proper operation of your Octophon phone. These instructions should be strictly complied with to avoid operating errors and ensure optimum use of your multifunctional telephone.


These instructions should be read and followed by every person installing, operating or programming an Octophon phone.

 For your own protection, please read the section dealing with safety in detail. Follow the safety instructions carefully in order to avoid endangering yourself or other persons and to prevent damage to the unit.

This user guide is designed to be simple and easy to understand, providing clear step-by-step instructions for operating your Octophon phone.

Administrative tasks are dealt with in a separate manual. The Quick Reference Guide contains quick and reliable explanations of frequently used functions.

Service

 The Telekom Service can only help you if you experience problems or defects with the phone. Should you have any questions regarding operation, your specialist retailer or network administrator will gladly help you. For queries regarding connection of the telephone, please contact your network provider.

If you experience problems or defects with the phone, please dial the service number for your country.

Intended use

The Octophon phone was developed as a device for speech transmission and should be placed on the desk or mounted on the wall. Any other use is regarded as unauthorized.

Telephone type

The phone name data can be found on the name plate on the base of the device; The exact product name and serial number are specified here.

Specific details concerning your communications platform can be obtained from your service technician.

Please have this information ready when you contact our service department regarding faults or problems with the product.

Speakerphone quality and display legibility

- To ensure good speakerphone quality, the area in front of the microphone (front right) should be kept clear. The optimum speakerphone distance is 50 cm.
- Proceed as follows to optimize display legibility:
 - Turn the phone to tilt the display to ensure you have a frontal view of the display while eliminating light reflexes.
 - Adjust the contrast as required → Page 110.

Multi-line telephone, executive/secretary functions

Your Octophon F615 TDM is a "multi-line telephone". This means that your service personnel can configure multiple lines on your phone, which is not the case with single-line phones. Each line is assigned an individual phone number which you can use to make and receive calls.

The programmable sensor keys function as line keys on multi-line phones → Page 91.

When using a multi-line phone to make and receive calls, certain particulars must be taken into account → Page 92 ff.

The executive-secretary configuration is a special case. This is a multi-line telephone with special features (e.g., "Ring Transfer" and "Accept call"), configured especially for executive/secretary use → Page 90 ff.


Team functions



To increase the efficiency of telephony, your service personnel can configure various Team functions such as pickup groups, hunt groups, and call distribution groups.

Getting to know your Octophon phone

The following sections describe the most frequently used operating elements and the displays on your phone.

The user interface of your Octophon F615 TDM



1	You can make and receive calls as normal using the handset .
2	The display permits intuitive operation of the phone → Page 17.
5	Audio keys are also available, allowing you to optimally configure the audio features on your telephone → Page 14.
4	 mailbox key and  menu key .
5	The keypad is provided for input of phone numbers/codes.
6	You operate the → Page 14 telephone with the navigation keys .
3	The programmable sensor keys can be assigned with functions (e. g. Disconnect) → Page 59.

Properties of your Octophon F615 TDM

Display type	LCD, 24 x 2 characters
Full-duplex speakerphone function	✓
Wall mounting	✓

key module for Octophon F615

The key module is a key module attached to the side of the phone that provides an additional 18 illuminated, programmable sensor keys.

Like keys on the phone, these keys can be programmed and used according to your needs
→ Page 15.



You can only attach one key module to your Octophon F615 TDM.

Keys

Audio keys



Key	Function when key is pressed
	Reduce volume and set contrast brighter → Page 110.
	Turn speaker on/off (with red LED key) → Page 23.
	Increase volume and set contrast darker → Page 110.


Mailbox key and Menu key



Key	Function when key is pressed
	Open mailbox (with red LED key) → Page 18.
	Open Program/Service menu (with red LED key) → Page 20.

Navigation keys


These are used to manage most of your phone's functions and display.




Key	Function when key is pressed
	Open the idle menu → Page 17 or browse back in the menu.
	Perform action.
	Open the idle menu → Page 17 or browse forward in the menu.

Programmable function keys

Your Octophon F615 TDM has eight illuminated keys to which you can assign functions or numbers.


 Increase the number of programmable function keys by connecting a key module
→ Page 13.



Depending on how they are programmed, you can use the keys as:

- Function keys → Page 59
- Redial/Direct station selection key → Page 64

Each key can be programmed with one function.

 The configuration of direct station selection keys must be activated by your service personnel.

Direct station selection keys can be assigned an internal number from the Octopus F900 network.




Press the key briefly to activate the programmed function or dial the stored number.

Hold the key to open the key programming menu → Page 59.


Your Octophon is delivered with label strips. Write functions or names in the white fields on the label strips.

The status of a function is shown by the LED on the corresponding function key.

Meaning of LED displays on function keys


LED		Meaning of function key
	Off	The function is deactivated.
	Flashing ^[1]	The function is in use.
	On	The function is activated.

[1] In this manual, flashing sensor keys are identified by this icon, regardless of the flashing interval. The flashing interval represents different statuses, which are described in detail in the corresponding sections of the manual.

 The programmable sensor keys on multi-line phones function as trunk keys
→ Page 91.

Keypad

In cases where text input is possible, you can use the keypad to input text, punctuation and special characters in addition to the digits 0 to 9 and the hash and asterisk symbols. To do this, press the numerical keys repeatedly.

Example: To enter the letter "h", press the number  key on the keypad twice.



To enter a digit in an alphanumerical input field, hold down the relevant key.

Alphabetic labeling of dial keys is also useful when entering vanity numbers (letters associated with the phone number's digits as indicated on the telephone spell a name, e.g. 0700-PATTERN = 0700 - 7288376).


Display

Your Octophon F615 TDM comes with a black-and-white LCD display. Adjust the contrast to suit your needs → Page 110.

Idle mode

Your phone is in idle mode when there are no calls taking place or settings being made.

Example:



Idle menu

When in idle mode, press a key on the 3-way navigator → Page 14 to display the idle menu. You can call up various functions here. The idle menu includes selected functions from the Program/Service menu → Page 20.

The idle menu may contain the following entries:

- Caller list
- Forwarding on
- Lock phone
- Do not disturb on^[1]
- Advisory msg. on
- Ringer cutoff on
- Send message
- View sent message^[2]
- View callbacks^[3]
- Phonebook
- HF answerback on
- Suppress call ID
- Call waiting tone off
- DISA intern

[1] Must be activated by service personnel.

[2] Only appears when there are messages that the recipient has not yet viewed

[3] Only appears if callback requests are saved


Mailbox


Depending on the type and configuration of your communications platform (contact the relevant service personnel), messages from services, such as IVM are displayed in this application in addition to messages received.

Messages


You can send short text messages to individual internal stations or groups.


In idle mode (→ Page 17) the following signals alert you to the presence of new messages:

-  key LED lights up
- Display "Messages received".

Press the mailbox key .

Example:



 For a description of how to edit the entries → Page 78.

Voicemail

If your telephone is connected to a voicemail system (such as Entry Voice Mail), the Mailbox key will also light up to alert you to any messages that have arrived.

An appropriate message also appears on the display (for instance, in Entry Voice Mail: "X new messages").

To play back your voicemail, follow the instructions on the display.

Caller list

If you are unable to accept an external or internal call, the call attempt is stored in the caller list.

Answered calls can also be saved (contact your service personnel).


Your telephone stores up to ten calls in chronological order. Each call is assigned a time stamp. The most recent entry not yet answered in the list is displayed first. Multiple calls from the same caller do not automatically generate new entries in the caller list. Instead, only the most recent time stamp for this caller is updated and its number incremented.


The caller list is automatically displayed → Page 17 in the idle menu → Page 39.

 Callers with suppressed numbers cannot be saved in the call log.

Information is displayed regarding the caller and the time at which the call was placed.

Example:




 For a description of how to edit the call logs → Page 39.

Program/Service menu

Use the  menu key to reach the Program/Service menu for your communication system.

The menu key LED remains red as long as you are in this menu.

Example:



A double arrow next to an entry indicates the availability of additional options for this entry. The menu structure comprises several levels. The first line in this structure shows the menu currently selected while the second line shows an option from this menu.

Step by Step

Basic functions



Please read the introductory chapter "Getting to know your Octophon F615 phone" → Page 12 carefully before performing any of the steps described here on your phone.

Answering a call

Special default ring signaling is set for your telephone:

- When you receive an internal call, your telephone rings once every four seconds (single-tone sequence).
- When you receive an external call, your telephone rings twice in rapid succession every four seconds (dual-tone sequence).
- When you receive a call from the entrance telephone, your telephone rings three times in rapid succession every four seconds (triple-tone sequence).
- If a call is waiting, you hear a short tone (beep) every six seconds.




Your service personnel can adjust the ring cadence for external and internal calls for you. In other words, different ring cadences can be set for different internal callers.

The number or the name of the caller appears on the display.

Answering a call via the handset

The phone is ringing. The caller appears on the screen.

Lift the handset.



Raise or lower the volume. Keep pressing the key until the desired volume is set.

Step by Step

Answering a call via the loudspeaker (speakerphone mode)



Suggestions for using speakerphone mode:

- Tell the other party that you are using speakerphone mode.
- The speakerphone works best at a low receiving volume.
- The ideal distance between the user and the telephone set in speakerphone mode is about 50 cm (approx. 20 inches).

The phone rings. The caller appears on the screen.



Press the key shown. The LED lights up.

if nec.  or 

Raise or lower the volume. Keep pressing the key until the desired volume is set.

Ending a call




Press the key shown. The LED goes out.

Step by Step

Switching to speakerphone mode

Prerequisite: You are conducting a call via the handset.




Hold down the key and replace the handset. Then release the key.

Set the call volume. Keep pressing the key until the desired volume is set.

U.S. mode

If the country setting is set to U.S. (ask the service personnel), you do not have to hold down the loudspeaker key when replacing the handset to switch to speakerphone mode.



Press the key shown.

Replace the handset. Proceed with your call.

Set the call volume. Keep pressing the key until the desired volume is set.

Switching to the handset

Prerequisite: You are engaged in a call in speakerphone mode.



Lift the handset. Proceed with your call.

Open listening in the room during a call

You can let other people in the room join in on the call. Let the other party know that you have turned on the speaker.

Prerequisite: You are conducting a call via the handset.

Activating



Press the key shown. The LED lights up.

Deactivating



Press the key shown. The LED goes out.

Step by Step

Making calls

Off-hook dialing



Lift the handset.



Internal calls: Enter the station number.
External calls: Enter the external code and the station number.

The called party does not answer or is busy:



Replace the handset.

On-hook dialing



Internal: Enter the station number.
External calls: Enter the external code and the station number.



Your system may also be programmed so that you have to press the Internal key before you dial an internal number. To call an external party, you have to enter an external code before dialing the party's telephone number (Prime Line is not active; contact your service personnel).

The other party answers with speaker:



Lift the handset.

or

On-hook dialing: Speakerphone mode.

The called party does not answer or is busy:



Press the key shown. The LED goes out.

Dialing with DDS keys

Prerequisite: You have saved a number on a DDS key → Page 64.



Press the key with a saved number.
If the number is saved on the second layer, press the shift key first.



You can press the DDS key during a call and automatically initiate a callback → Page 27.

Step by Step

Redialing a number

The last three external telephone numbers dialed are stored automatically.



If this feature is configured (contact your service personnel), account codes entered are also saved → Page 68.

You can redial them simply by pressing a key.

Displaying and dialing saved station numbers

Prerequisite: The "Redial" key is configured.



Press the "Redial" key to dial the last number dialed.

Press the key twice to dial the next to the last number dialed.

Press the key three times to dial the third-to-the-last number dialed.

or

Next?

Keep confirming until the phone number you want appears.

Call?

Select and confirm the option shown.

Ending a call



Press the lit key.

or



Replace the handset.

Step by Step

Reject calls

You can reject calls which you do not wish to take. The call is then signaled at another definable telephone (contact your service personnel).

Prerequisite: The "Disconnect" key is configured. The phone rings. The caller appears on the screen.

 Press the "Disconnect" key.

If a call cannot be rejected, your telephone will continue to ring. The message "currently not possible" is displayed (e. g. in the case of re-calls).


Turning the microphone on and off

To prevent the other party from listening in while you consult with someone in your office, you can temporarily switch off the handset microphone or the handsfree microphone. You can also switch on the handsfree microphone to answer an announcement via the telephone speaker (speaker call, → Page 35).

Prerequisite: A connection is set up, the microphone is activated. The "Microphone" key is configured

 Press the "Microphone" key. The microphone is deactivated.

or

 Press the illuminated "Microphone" key. The microphone is activated.

Step by Step

Consult?



Return to held call?

or

Quit and return?

Alternate?

Conference?

Leave conference?

Calling a second party (consultation)

You can call a second party while a call is in progress. The first party is placed on hold.

Confirm the option shown.

Call the second party.

Return to the first party:

Confirm,

select and confirm the option shown

Switching to the held party (alternating)

Select and confirm the option shown.

Combine the calling parties into a three-party conference

Select and confirm the option shown.

Allowing call partners to continue a conference after you exit

Select and confirm the option shown.



For more information on conferences, see → Page 51.

Step by Step

Consult?



or

Transfer?

Transferring a call

If the person you are speaking to wants to talk to another colleague of yours, you can transfer the call that colleague.

Confirm the option shown.

Enter the number of the party to which you want to transfer the call.

Announce the call, if necessary.

Replace the handset.

Select and confirm the option shown¹.

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Call forwarding

Using variable call forwarding

You can immediately forward internal or external calls to different internal or external telephones (destinations). (External destinations require special configuration in the system.)



When call forwarding is active, a special dial tone sounds when you lift the handset.

If DID DTMF is active (contact your service personnel), you can also forward calls to this destination.
Destinations: Fax = 870, DID = 871, Fax-DID = 872.

If you are a call forwarding destination, your display will show the number or the name of the originator on the upper line and that of the caller on the lower line.



Special features must be taken into consideration if your telephone operates with IP-Netpackage (system networking via PC network) → Page 105!



If configured: Press the "Call forwarding" key.

or



Open the idle menu → Page 17.

Forwarding on?

Select and confirm the option shown.

1=all calls?

Confirm,

or

2=external calls only?

select and confirm the option shown,

or

3=internal calls only?

select and confirm the option shown



Enter the destination number.

Save?

Confirm the option shown.

Deactivating call forwarding



Press the key.

or

Forwarding off

Select and confirm the option shown.

Step by Step

Using call forwarding no reply (CFNR)

Calls that are not answered after three rings (=default, can be adjusted by service personnel) or that are received while another call is ongoing can be automatically forwarded to a specified telephone.



Press the key shown.

*495=CFNR on?

Select and confirm the option shown.



Enter the destination number.

- Enter the internal station number for internal destinations
- Enter the external code and the external station number for external destinations

Save?

Confirm the option shown.



Press the key shown.

#495=CFNR off?

Select and confirm the option shown.

Delete?

Confirm the option shown.

or

End

Select and confirm to deactivate but not delete the forwarding destination.



If CFNR is activated "CFNR to: ..." appears briefly on the display after you hang up.

Step by Step

Call forwarding in the carrier network and forwarding multiple subscriber numbers (MSN)

If this function has been configured (contact your service personnel), you can forward calls to your assigned multiple subscriber number (MSN) (DID number) directly within the carrier network. For example, you can forward your phone line to your home phone after business hours.



Press the key shown.

Trunk forwarding on?

Select and confirm the option shown.

1=immediately ?

Select and confirm the required type of call forwarding

or

2=unanswered calls?

select and confirm the option shown

or

3= on busy?

select and confirm the option shown



Enter your DID number.



Enter the destination number (without the external code).

Save?

Confirm the option shown.

Deactivating call forwarding

Trunk forwarding off?

Select and confirm the option shown.

Confirm the displayed call forwarding type.



Enter your DID number.

Step by Step

Using callback

You can request a callback if the internal station called is busy or if nobody answers. This also applies for external calls via ISDN exchanges. This feature saves you from having to make repeated attempts to reach the user.

You receive a callback

- When the other party is no longer busy,
- When the user who did not answer has conducted another call.



When configured (contact your service personnel), all callback requests are automatically deleted over night.

Storing a callback

Prerequisite: You have reached a busy line or no one answers.

Confirm the option shown.

Callback?

Accepting a callback

Prerequisite: A callback was saved. Your telephone rings and "Callback: ..." appears on the display.



Lift the handset.

or



Press the key shown. The LED lights up.

or

Answer?

Select and confirm the option shown.

You hear a ring tone.

Step by Step



Open the idle menu → Page 17.

View callbacks?

Select and confirm the option shown¹.

Display next?

Select and confirm to display additional entries.

Delete?

Confirm the option shown.

End?

Select and confirm the option shown.

or



Press the key shown. The LED goes out.

or



Press the key shown. The LED goes out.

Viewing and deleting a stored callback

Deleting a displayed entry

Ending retrieval

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Enhanced phone functions

Answering calls

Accepting a specific call for your colleague

You hear another telephone ring.



Press the key shown.

more functions?↕

Select and confirm the option shown.

*59=Accept, directed?

Select and confirm the option shown¹.

if nec.

Next?

Select and confirm until the name/number of the required subscriber is displayed.

Accept call?

Confirm the option shown.

or



If you know the number of the telephone that is ringing, enter it directly.

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Using the speakerphone

A colleague addresses you directly over the speaker with a speaker call. You hear a tone before the announcement. The other party's name or station number appears on the screen.

You can conduct the call with the handset or in speakerphone mode.



or

Microphone on?

Press the "OK" key to confirm your selection and answer the call.



If handsfree answerback is enabled (see below), you do not need to switch on the microphone - you can answer directly. You can answer immediately in speakerphone mode.

If handsfree answerback is disabled (default setting), follow the procedure described above.

Placing a speaker call to a colleague → Page 44.

Enabling and disabling handsfree answerback



Open the idle menu → Page 17.

HF answerback on?

Select and confirm the option shown.

or

HF answerback off?

select and confirm the option shown

Step by Step

Answering calls from the entrance telephone and opening the door

If an entrance telephone has been programmed, you can use your telephone to speak to someone at the entrance telephone and to activate a door opener.

If you have the proper authorization (contact your service personnel), you can activate the **door opener**, enabling visitors to open the door themselves by entering a 5-digit code (using a DTMF transmitter or the keypad installed).

Speaking to visitors via the entrance telephone

Prerequisite: Your telephone rings.



Lift the handset within thirty seconds. You are connected to the entrance telephone immediately.

or



Lift the handset after more than thirty seconds.



Dial the entrance telephone number.

Opening the door from your telephone during a call from the entrance telephone

Open door?

Confirm the option shown.

Opening the door from your telephone without calling the entrance telephone



Press the key shown.

*61=Door opener?

Select and confirm the option shown.



Dial the entrance telephone number.



Special features must be taken into consideration if your telephone operates with IP-Netpackage (system networking via PC network) → Page 109!

Opening the door with a code (at the door)



After ringing the bell, enter the five-digit code (using the keypad or a DTMF transmitter). Depending on how the door opener has been programmed, a doorbell call signal may or may not be forwarded.

Step by Step



***89=Door opener on?**



or

3=Change password?

or

1=enable with ring?

2=enable without ring?



#89=Door opener off?



Activating the door opener

Press the key shown.

Select and confirm the option shown.

Dial the entrance telephone number.

Enter the five-digit code. Default code = "00000".

Select the displayed function and press the "OK" dialog key to change the code.

Select and confirm the option shown.

You can also open the door without a doorbell ring.

Deactivating the door opener

Press the key shown.

Select and confirm the option shown.

Accepting a call from an answering machine

If an answering machine is connected to your system (ask the responsible technician) and you have programmed the answering machine's internal number on a key → Page 59, you can accept the call from the answering machine.

The LED lights up. Press the key shown.

Step by Step

Making calls

En-bloc sending/correcting numbers

If this feature is configured (contact your service personnel), a connection is not attempted immediately when a station number is entered. This means that you can correct the number if necessary. The station number is only dialed at your specific request.



Internal calls: Enter the station number.
External calls: Enter the external code and the station number.

Dialing entered/displayed numbers



Lift the handset.

or

Dial?

Confirm the option shown.

Correcting numbers entered



A station number can only be corrected as it is being entered. Station numbers stored for number redial, for example, cannot be corrected.

Delete digit?

Select and confirm the option shown.
The last digit entered in each case is deleted.



Enter the required digit(s).

Canceling en-bloc sending

Cancel?

Select and confirm the option shown.

or



Press the key shown. The LED goes out.

Step by Step

Using the caller list

Detailed information, as well as a sample display entry are provided on → Page 19.

Retrieving the caller list

Prerequisite: Service personnel has set up a caller list for your telephone.

Open the idle menu → Page 17.

Confirm¹.

The latest entry is displayed, see the example on → Page 19.

To view other calls, confirm each subsequent display.

Ending retrieval

Select and confirm the option shown.

or



Press the key shown. The LED goes out.

or



Press the key shown. The LED goes out.

Displaying the call time

Prerequisite: You have retrieved the caller list and the selected call is displayed → Page 19.

Select and confirm the option shown.

Dialing a station number from the caller list

Prerequisite: You have retrieved the caller list and the selected call is displayed.

Select and confirm the option shown.



The caller is automatically deleted from the caller list when a connection is finally set up.

Removing an entry from the caller list

Prerequisite: You have retrieved the caller list and the selected call is displayed.

Confirm the option shown.



Caller list?

Next?

Back?

When?

Call?

Delete?

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Dialing a number from the internal directory

The internal directory contains all station numbers and system speed-dial numbers assigned to a name. Contact your service personnel to find out if one was configured for your system.

Prerequisite: Names have been assigned to the station numbers stored in the system.



Lift the handset.

or



Press the key shown. The LED lights up.

Phonebook?

Confirm the option shown.


if nec.

If several directories have been configured:

1=internal calls?

Confirm the option shown.

The first entry is displayed on the screen.



Scroll to next or previous entry.

or

Scroll forward?

select and confirm the option shown,

or

Scroll back?

select and confirm the option shown

or



Enter the name you want to find, or just the first few letters, using the alphanumeric keypad → Page 16.

if nec.

Delete letter?

Select and confirm each letter to be deleted. The last letter entered is deleted. If all letters are deleted, the first entry in the directory will be displayed again.

if nec.

Delete line?

Select and confirm the option shown. All entered letters are deleted, and the first entry in the internal directory is displayed again.

The entry you wish to dial appears on the screen

Call?

Select and confirm the option shown.

Step by Step

Using the LDAP directory

If configured (ask your service personnel), you can search for directory data in the LDAP database and dial the number of any subscriber you find there.

Prerequisite: The LDAP search feature has been configured in the system.



or



Lift the handset.

Press the key shown. The LED lights up.

Phonebook

Confirm the option shown.

if nec.

If several directories have been configured:

2=LDAP?

Select and confirm the option shown.



Enter the name you wish to search for using the keypad (max. 16 characters) → Page 16.

You can enter an incomplete name, e.g. "mei" for "Meier".

if nec.

If configured (ask your service personnel), you can also search for surname and first name. To separate surname and first name by a space, enter "0". You can enter incomplete names, e.g. "mei p" for "Meier Peter".

if nec.

Delete letter?

Select and confirm each letter to be deleted. The last letter entered is deleted.



In large databases, the results of the search may be incomplete if too few characters are entered → Page 42.

Search?

Confirm the option shown.

The name is searched for. This may take a few seconds.

Step by Step

Call?

or

or

Scroll forward?

or

Scroll back?

Call?

Modify search?

Display results?

or

Modify search?

The result is displayed

If only one name is found, it is displayed.
Confirm the option shown.

If several names are found (max. 50), the first name is displayed.

Scroll to next or previous entry,

confirm,

select and confirm the option shown

Select and confirm the option shown.

If no name is found

If your search does not yield any name corresponding to your query, you can extend the range of the search, e.g. by deleting characters.

Select and confirm the option shown.
For further procedure, see above.

If too many names are found

If more than the maximum of 50 names are found corresponding to your query, only an incomplete list of results can be displayed.

You can view these results, select any of the names, or change the search string (e.g. narrow the search by entering more characters).



In this case it is advisable to narrow down the search so that all corresponding names can be displayed.

Confirm, to view the incomplete list.
For further procedure, see above.

Narrow the search down.

Select and confirm, in order to change the search string.
For further procedure, see above.

Step by Step

Making calls using system speed-dial numbers

Prerequisite: You know the system speed-dial numbers (consult your service personnel).



Press the key shown.

*7=Use speed dialing?

Select and confirm the option shown^[1].



Enter a three-digit speed-dial number.

if nec.

Suffix-dialing



If necessary, you can suffix-dial additional digits (for example, the user's extension) at the end of the saved station number.

If this feature is configured, a suffix is automatically dialed (for example, "0" for the exchange) if no entries are made within 4 or 5 seconds.

Dialing with speed-dial keys

Prerequisite: You have configured speed-dial keys → Page 43.



Press the key shown.

*7=Use speed dialing?

Select and confirm the option shown^[1].



Press the key shown.



Press the required speed-dial key.

Configure a speed-dial key

You can program the keys + to with ten frequently used phone numbers.



Press the key shown.

*92=Change speed dial?

Select and confirm the option shown^[1].

Modify?

Confirm the option shown.



Press the key shown.



Press the required speed-dial key. If the key is already in use, the programmed phone number appears on the screen.

Changing the

Confirm the option shown.

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step



First enter the external code and then the external station number.

save

Confirm the option shown.

or

If you make a mistake:

Back?

Select and confirm the option shown. This deletes all entered digits.

next destination?

Confirm the option shown.

or

Modify?

Select and confirm the option shown.

or

Delete?

select and confirm the option shown,

or

End?

select and confirm the option shown

Talking to your colleague with a speaker call

You can make a loudspeaker announcement through a loudspeaker if connected (ask your service personnel), or to an internal user with a system telephone without any action on their part.



Open the idle menu → Page 17.

*80=Speaker call?

Select and confirm the option shown.



Enter the station number.




Responding to a speaker call → Page 35.

Step by Step

Talking to your colleague with discreet calling

If this function has been configured (ask your service personnel), you can join an ongoing call conducted by an internal user at a system telephone with display.

You can listen in unnoticed and speak to the internal user without being overheard by the other party (discreet calling).



Lift the handset.

Enter the code.



Enter your internal station number.



Your service personnel can protect your telephone against discreet calling.

Automatic connection setup (hotline)

If this function is configured (contact your service personnel), the system automatically sets up a connection to a preset internal or external destination.



Lift the handset.

Depending on the setting, the connection is either set up **immediately** or only **after** a preset **period of time** (hotline after a timeout).

Reserving a trunk

If configured (ask your service personnel), you can reserve an occupied trunk for yourself.

When the line is free, you receive a call and a note on the display.

Prerequisite: "Currently busy" appears on the display.

Confirm.

Reserve trunk

Reserved line is free:

Your telephone rings and the display shows "Trunk is free".



Lift the handset. You will hear the dial tone.



Enter the external phone number.

Step by Step

Assigning a station number

If this function has been configured (contact your service personnel), you can selectively assign a specific number (DID number) to your telephone before making an external call. The assigned number then appears on the called party's display.



Press the key shown.

*41=Assign number?

Select and confirm the option shown.



Enter the DID number you wish to use.



Dial the external number.

Associated dialing/dialing aid

If this function has been configured (contact your service personnel), you can use a dialing aid to dial numbers and set up calls for your telephone.

The operating procedure depends on whether the dialing aid is connected to the **S₀ bus** or the **a/b (T/R) port**.

You can also use your system telephone as a dialing aid for other telephones.

Dialing aid on the S₀ bus

On the PC, select a destination and start dialing.



The speaker on your telephone is switched on. Lift the handset when the other party answers.

Dialing aid at the a/b (T/R) port

On the PC, select a destination and start dialing.

"Lift the handset" appears on the PC screen.



Lift the handset.

Dialing aid from your telephone for another telephone:



Press the key shown.

*67=Associated dialing?

Select and confirm the option shown.



Enter the internal station number ("Dial for:").



Enter the number you wish to dial.

Step by Step

During a call

Using call waiting (second call)

Callers can still reach you while you are engaged in another call. A signal alerts you to the waiting call. You can ignore or accept the second call. When you accept the waiting call, you can either end the first call or place it on hold and resume the call later on. You can block the second call or the signal tone (→ Page 48).

Prerequisite: You are engaged in a phone call and hear a tone (every six seconds).

Ending the first call and answering the waiting call:



Replace the handset. Your telephone rings.



Answer the second call. Lift the handset.

Placing the first call on hold and answering the second call:

Accepting call waiting?

Select and confirm the option shown.

You are immediately connected to the second caller. The first party is placed on hold.

Quit and return?

Ending the second call and resuming the first one

Confirm the option shown.

or



Replace the handset. "Recall:..." appears on the display.



Lift the handset.

Step by Step

Preventing and allowing call waiting (automatic camp-on)

If this function has been configured (ask your service personnel), you can prevent or allow a second call → Page 47 from being signaled by automatic camp-on during an ongoing call.



Press the key shown.

#490=Call wait.term.off?

Select and confirm the option shown¹,

or

*490=Call wait.term.on?

select and confirm the option shown

Turning the call waiting tone on and off

You can suppress the call waiting tone (every six seconds) for external calls. A one-time special dial tone then alerts you to the waiting call.

Activating



Open the idle menu → Page 17.

Call waiting tone off?

Select and confirm the option shown.

Deactivating



Open the idle menu → Page 17.

Call waiting tone on?

Select and confirm the option shown.

Saving a number

You can save your call partner's station number for subsequent redialing from the caller list → Page 39.

Prerequisite: You are conducting a call.

Save number?

Select and confirm the option shown.

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Parking a call

You can park up to ten calls, either internal, external, or both. Parked calls can be displayed on and picked up from another telephone. This feature is useful if you want to continue a call at another phone.

Prerequisite: You are conducting a call.



Press the key shown.

*56=Park call?

Select and confirm the option shown.



Enter the number of the park slot (0 - 9) and make a note of it. If the park slot number you entered is not displayed, it is already in use; enter another one.

Retrieving a parked call

Prerequisite: One or more calls have been parked. The phone is idle.



Press the key shown.

Retrieve call?

Select and confirm the option shown¹.



Enter the park slot number you noted earlier. If the park slot number you enter is not in use, you cannot retrieve the call.



If a parked call is not picked up, after a specific period of time the call is returned to the telephone from where it was parked (recall).


[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Held on line: 801



if nec.



Retrieve line

or



or



Holding external calls

If you have programmed a hold key on your phone → Page 59, you can put external calls on hold.

Then all other stations can accept the call on the assigned trunk.

Press the "Hold" key.

The message of the relevant trunk appears (e.g. 801) and note the trunk number.

If available, the LED of the assigned trunk key flashes slowly.

Replace the handset or press the key shown.

Depending on the configuration, this may be necessary so other members can also pick up the call on hold.

Accepting call on hold

Prerequisite: One or more calls are on hold. The phone is idle.

Open the Program/Service menu → Page 20.

Select and confirm the option shown.

If the "Retrieve" → Page 59 key is available, press it.

Enter the noted trunk number.

If there is a "Line:" key available for the relevant trunk, this flashes slowly. Press the key shown.

Step by Step

Conducting a conference

In a conference call, you can talk to as many as four other parties at the same time. These may be internal or external users.



You can only add parties to or remove them from a conference if you initiated the conference.



Start conference?

Call the first party.

Select and confirm the option shown.



Conference?

Call the second party. Announce the conference.

Select and confirm the option shown.

A tone sounds every 30 seconds to indicate that a conference is in progress.

If the second party does not answer

Confirm the option shown.

Adding up to five parties to a conference

Confirm the option shown.



Add party?

Call the new party. Announce the conference.

Conference?

Select and confirm the option shown.

Viewing the conference parties

Select and confirm the option shown. The first party is displayed.

View conf parties?

To display other parties, confirm each subsequent display.

Next?

To exit the list: Select and confirm the option shown.

Exit list?

Removing parties from the conference

Select and confirm the option shown. The first party is displayed.

View conf parties?

Confirm as often as required until the desired party appears.

Next?

Select and confirm the option shown.

Remove party?

Step by Step

Leave conference?

or



Select and confirm the option shown.

Replace the handset, if this feature is configured (contact your service personnel).

End conference?

or



Select and confirm the option shown.

Replace the handset, if this feature is configured (contact your service personnel).

Drop last conf. party?

Select and confirm the option shown.

Leaving a conference

Ending a conference

Removing the ISDN central office party from the conference

Step by Step

Activating tone dialing/DTMF suffix-dialing

You can transmit dual-tone multifrequency (DTMF) signals to control devices such as an answering machine or automatic information system.



Press the key shown.

*53=DTMF dialing?



Select and confirm the option shown.

You can use the keys **[0+]** through **[9wxyz]**, **[*]** and **[#]** to transmit DTMF signals.



Ending the call also deactivates DTMF suffix dialing.

Your system may be configured so that you can start DTMF suffix-dialing immediately after setting up a connection.

Step by Step

Recording a call

If configured (contact your service personnel for details), you can record an active call.

Prerequisite: You are on a call, the "Recording" key is configured → Page 59.



Press the "Recording" key. The LED lights up.

You and the other party hear an announcement that recording has started and as long as recording is still running, you hear an acoustic signal approx. every 15 seconds.



During recording, it is not possible to add further call parties.

Stopping recording



Press the "Recording" key which lights up. The LED goes out.

Listening to a recording

Playback of the recording depends on the voice recording system used (see the associated user guide).

Step by Step

Transferring a call after a speaker call announcement in a group

If this function has been configured (contact your service personnel), you can use a speaker call (announcement, → Page 99) to announce a call in progress to a group of users → Page 44. After a member of the group has accepted the call request, you can transfer the waiting party.

Prerequisite: You are conducting a call.

Consult?

Confirm the option shown. The other party is placed on hold.



Press the key shown.

*80=Speaker call?

Select and confirm the option shown.



Enter the group's station number.



Announce the call.

When a member of the group accepts the call → Page 35, you are connected to this party.



Replace the handset.

or

Transfer?

Select and confirm the option shown¹.



If the connection between the two other parties is not established within 45 seconds, the call from the first party returns to you (recall).

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Send trunk flash

To activate ISDN-type services and features through the network carrier's analog trunks or those of other communications platforms (such as "consultation hold"), you must send a signal to the trunks before dialing the service code or telephone number.

Prerequisite: You have set up an external connection.



Press the key shown.

*51=Trunk flash?

Select and confirm the option shown.



Enter the service code and/or telephone number.

Step by Step

If you cannot reach a destination

Call waiting (camp-on)

Prerequisite: You have dialed an internal number and hear a busy signal. It is important that you reach the called party.

Wait (approx. 5 seconds) until "Camp-on" appears on the display and the busy tone is followed by the ringtone.

The called party can then respond → Page 47.



The called party can prevent automatic call waiting
→ Page 48.

If this feature is configured (contact your service personnel), you will hear the ring tone and the message "Camp-on" is immediately displayed.

Camp-on

Busy override – joining a call in progress

This function is only available if it has been configured by the service technician (contact your service personnel).

Prerequisite: You have dialed an internal number and hear a busy signal. It is important that you reach the called party.

Select and confirm the option shown.

The called party and person to whom this party is talking hear an alerting tone every two seconds.

If the called party has a system telephone with display, the following appears on the screen: "Busy override: (Number or name)".

You can now start talking.

Busy override?

Step by Step

Night answer on?

*=default?

or



or



Save?

Night answer off?

Using night answer

When night answer mode is active, for example during a lunch break or after office hours, all external calls are immediately forwarded to a specific internal telephone (night station). The night station can be defined by service personnel (standard night answer service) or by you (temporary night answer service).



Special features must be taken into consideration if your telephone operates with IP-Netpackage (system networking via PC network) → Page 106!

Activating

Select and confirm the option shown.

Press the "OK" dialog key to confirm (standard night answer service).

or

Enter the code (standard night answer service).

or

Enter the destination number (temporary night answer service).

Confirm the option shown.

Deactivating

Select and confirm the option shown.

Service personnel can also configure an "automatic night answer service". The automatic night answer service activates at specific times for your telephone depending on how it is programmed. You can deactivate the automatic night answer service or replace it with a night answer service you configured (see above).


Step by Step

Programming the function keys


You can program frequently used functions, station numbers or procedures onto the function keys on your Octophon F615 TDM or key module.

Configuring function keys

See also → Page 15.


 A list of all available functions is displayed, see the overview → Page 60.

Example: Programming the Shift key


 Hold down the key shown.

Assign telephony function


or

 Open the Program/Service menu → Page 20.

Prog. feature key

 Press the key shown.

Change key

More features  Select and confirm the option shown.

Shift Key

if nec.

Save incomplete

Select and confirm the option shown.

End

or

Another key

Select and confirm the option shown.

Hold down the key shown.

Confirm the option shown.

or

Open the Program/Service menu → Page 20.

Select and confirm the option shown.

Press the key shown.

Confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

if nec.

Select and confirm the option shown.

Some functions (e. g. with "Call forwarding") cannot be saved completely. This means that when later initiating the function by pressing the button, further inputs are required.

Confirm the option shown.

or

Select and confirm the option shown.

The LED displays → Page 15 and → Page 60 show the status of the function.

Step by Step

Overview of functions

The functions are split into the following menus:

- Destinations
- Control relays
- PIN and authorization
- Calls
- More features



The available functions depend on your configuration. If a function is missing, contact your service personnel.

Saved function LED messages

Call forwarding, Forwarding - trunk, Forward Line, Night answer, Do not disturb, Telephone lock, Advisory message, Silent, HF answer-back on/off, Group call on/off, Caller ID suppression, Call wait.term., Call waiting tone off, Ring Transfer, Recording, Door opener on/off, Control relay, Group ringing, Shift Key, UCD(available on/off, Work on/off, Night answer on/off, MULAP privacy release:



Saved function is not activated.



Saved function is activated.

Callback:



You have no entry for callback.



You have an entry for callback.

Internal number, DSS:



Party not on a call.



Party is on a call or has activated DND.



Flashing quickly - I'm being called, please accept.

Flashing slowly - another party is being called and has not yet answered.

Call key, General call key, Trunk key, MULAP Key, Assign number:



No call via corresponding trunk.



Active call via the corresponding trunk.



Flashing quickly - call on the corresponding trunk, call pickup is possible by pressing the key.

Flashing slowly - a call is placed on hold on the relevant trunk.

Step by Step

Trunk group key:



At least one trunk is free.



All lines in this trunk group are occupied.

View call charges:



No chargeable calls have been set up since the last check.



Chargeable calls have been set up since the last check.

Call forwarding, Forward line:



Flashing slowly - your line is a call forwarding destination.

Fax/answering machine details.:



No fax received or no message on the answering machine.



Fax received or message on the answering machine.

View the number of calls:



No waiting callers.



Flashing quickly - callers waiting (certain number is exceeded).
Flashing quickly - callers waiting (certain number is reached).

Data I/O service:



No connection to an application.



Active connection to an application.



Flashing slowly, connection to an application is temporarily interrupted.

The following functions programmed on keys do not have a LED function:

Number (external) , Procedure key, Trace call, Speed dial, Clear, Lock all phones, Send message, Directory (1=internal, 2=LDAP), Accepting call waiting, Toggle/Connect, Conference, Speaker call, Retrieve line, Reserve trunk, Release line, Temporary Phone, Override, Park a call, Pickup - directed, Pickup - group, Account code, Show call charges, Page, Answer page, Timed reminder, Door opener, DTMF dialing, Signal key, Room monitor, Hold key, Internal consultation call , Consultation call, Associated dial, Associated serv., Tel. data service, Change number, Discreet calling.

Step by Step

Programming a procedure key

Numbers and functions which require further input, i.e. which contain several operating steps, can be saved on a key on your telephone. The relevant service personnel must be granted appropriate authorization.

For example the function "Associated dialing" → Page 46 together with the required input (phone number to be dialed) can be saved on a key.

Numbers which require further input can also be saved.



Open the Program/Service menu → Page 20.

Prog. feature key

Select and confirm the option shown.



Press the key shown.

Change key

Confirm the option shown.

More features



Select and confirm the option shown.

Procedure key



Select and confirm the option shown.



Enter procedure. Example: *67 231 123456



Code for associated dial



Number of the phone to for which the call should be made



the number to be called.

if nec.

Press the "Pause" key to enter pauses (a "P" appears on the display).

save

Confirm the option shown.

or

If you make a mistake:

Back

Select and confirm the option shown. This deletes all entered digits.

End

Confirm the option shown.

or

Another key

Select and confirm the option shown.

Step by Step



Select the saved procedure by pressing the key.
Procedures with activatable/deactivatable functions are activated with one press of the button and deactivated with the next.

You can press the procedure key during a call to automatically send the saved digits as DTMF signals → Page 53. For display messages when saving procedures, see → Page 115.

Step by Step

Configuring redial keys

You can also program internal and external station numbers on the second level. The LED function is not available for internal station numbers on the second level. To program the second level, you must program a "Shift" key → Page 59.

See also → Page 15.



Open the Program/Service menu → Page 20.

Prog. feature key

Select and confirm the option shown.



Press the key shown.

Change key

Confirm the option shown.

if nec.

+ = Next level

Select and confirm the option shown.

Destinations



Confirm the option shown.

Number

Confirm the option shown.



Enter the station number.

If you make a mistake:

Back

Select and confirm the option shown. This deletes all entered digits.

End

Confirm the option shown.

or

Another key

Select and confirm the option shown.



You dial the saved number by pressing the key → Page 24.
You can also save a number during a call.

Step by Step

Deleting function key programming



Open the Program/Service menu → Page 20.

***91=Prog. feature key**

Select and confirm the option shown.



Press and hold the assigned key.

Delete key

Select and confirm the option shown.

Step by Step

Displaying and assigning call charges

Displaying call charges

For the current call:

Call charges are shown by default on the display when a call ends. If you want to display call charges as they occur during a chargeable call, your service personnel must request this option from the network operator.

Call charge display must be requested from the network operator and configured by the relevant service personnel.

Depending on the setting, call charges are displayed during or after a call.

Depending on the network operator, free external calls are also displayed. The message "Free of Charge" appears on the screen either before or during the call.

If the cost indication facility has not been installed, the display will show the dialed number and/or the length of the telephone call.



If a call is forwarded, call charges are assigned to the destination of the call transfer operation.

For all calls and for the last call

Connection charges for the last chargeable call made are displayed first. After five seconds, the accumulated connection charge (total) is displayed.



Press the key shown.

***65=Show call charges?**

Select and confirm the option shown¹.

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Displaying call charges for another telephone

If configured (contact your service personnel), you can also display and print chargeable calls for another phone (for instance for a pay phone).

Prerequisite: You have programmed the function "Show call charges" on a key → Page 59.

The LED lights up to indicate that a you have conducted a chargeable call since the last time you viewed the charges.

Press the "Call Charges" key. Chargeable calls are displayed.

Next

Press to display further chargeable calls.

Print

Select and confirm the option shown,

or

Clear

select and confirm the option shown,

or

Add'l information

select and confirm the option shown,

or

Exit

select and confirm the option shown.

Step by Step

Dialing with call charge assignment

You can assign external calls to certain projects.

Prerequisite: Your service personnel have defined account codes for you.



Press the key shown.

*60=Account code?

Select and confirm the option shown.



Enter the account code.

if nec.



Press this key.

or

#=Save?

Confirm the option shown.

Depending on the required configuration; Contact your service personnel.



Enter the external phone number.



You can also enter the account code during a call.

Step by Step

Privacy/security

Turning ringer cutoff on and off

If you do not wish to take calls, you can activate the ringer cutoff function. Calls are only identified by **one** ring signal, and they are shown on the display.

Activating



Open the idle menu → Page 17.

Silent on?

Select and confirm the option shown¹,

Deactivating



Open the idle menu → Page 17.

Silent off?

select and confirm the option shown.

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Activating/deactivating "Do not disturb"

If you do not wish to take calls, you can activate do not disturb. Internal callers hear the busy tone, external callers are connected to another phone, which you can specify (contact your service personnel).

Activating



Open the idle menu → Page 17.

Do not disturb on?

Select and confirm the option shown.

Deactivating



Open the idle menu → Page 17.

Do not disturb off?

Confirm the option shown.



When you lift the handset, you will hear a special tone (continuous buzzing) reminding you that "Do not disturb" is activated.

Authorized internal callers automatically override the DND feature after five seconds.

Step by Step

Caller ID suppression

You can prevent your station number or name from appearing on the displays of external parties you call. The feature remains active until you deactivate it.

Activating


Open the idle menu → Page 17.

Select and confirm the option shown.

Deactivating

Open the idle menu → Page 17.

Select and confirm the option shown.

 Your service personnel can activate/deactivate caller ID suppression for all phones.

▼
Suppress number?

▼
Transfer number?

* 9 wxyz 4 ghi 4 ghi



Enter the code.

Enter your internal station number.

Silent Monitoring/Secret busy override

When configured (ask responsible service personnel), you can join in an on-going call conducted by an internal user and monitor silently and unnoticed.

Step by Step

*88=Room monitor?



Press the key shown.

Select and confirm the option shown.

You can either leave the telephone in speakerphone mode or lift the handset and leave it directed towards the noise source.

Deactivating the telephone to be monitored



Press the lit key. The LED goes out.

or



Replace the handset.

Monitoring the room



Enter the internal station number of the phone located in the room that you wish to monitor.

*84=Trace call?



Press the key shown.

Select and confirm the option shown.



If the trace is successful, the transmitted data is stored by your network operator. Contact your service personnel.

Step by Step

Locking the telephone to prevent unauthorized use

You can prevent unauthorized parties from using your phone during your absence.

Locking the phone



Open the idle menu → Page 17.

Lock phone?

Select and confirm the option shown.

or

Unlock phone?

select and confirm the option shown



Enter code (telephone lock) → Page 75.



When the phone is locked, a special dial tone sounds when the handset is lifted. Within the system, users can make calls as normal.

Your phone can also be locked or unlocked by an authorized party → Page 74.



Open the idle menu → Page 17.

Unlock phone

Select and confirm the option shown.



Enter code (telephone lock) → Page 75.

Unlocking the phone

Step by Step

Locking another telephone to prevent unauthorized use

If configured (contact your service personnel), you can lock and unlock other telephones to prevent unauthorized access.

If a phone user locks his or her phone and forgets the personal lock code, you can use this function to unlock the phone.



Press the key shown.

***943=Lock all phones?**

Select and confirm the option shown.



Enter the internal station number of the phone you wish to lock/unlock.

***=Phone lock on?**

Confirm,

or

#=Phone lock off?

select and confirm the option shown

Step by Step

Saving your PIN

Enter the lock code to use the functions

- for locking the telephone to prevent unauthorized use → Page 73
- for using another telephone like your own → Page 80.
- Change number → Page 81

You can save this code.



Press the key shown.

***93=Change PIN?**

Confirm the option shown.



Enter the current five-digit PIN.

If you have not yet set a PIN, use "00000" the first time.



Enter the new PIN.



Re-enter the new PIN.



If you forget your code, contact your service personnel. Your code can be reset to "00000".

Step by Step

More functions/services

Appointments function

You can configure your phone to call you to remind you about appointments → Page 77.

You must save the required call times. You can enter a single appointment that will take place in the next twenty-four hours or you can enter a daily recurring appointment.

Saving appointments



Press the key shown.

*46=Timed reminder on?

Confirm the option shown.



Enter 4-digit times e. g. 0905 for 9.05 (= 9.05 a.m.) or 1430 for 14.30 (= 2.30 p.m.).

possibly or

If the selected language is "US English" (settings → Page 112) you can enter the code 2 for "am" or 7 for "pm" (default = "am").

One time only?

Confirm the option shown.

or

Daily?

Select and confirm the option shown.

Save?

Confirm the option shown.



Press the key shown.

#46=Timed reminder off?

Confirm the option shown.

Delete?

Confirm the option shown.

or

End?

Select and confirm the option shown.

Deleting and checking a saved appointment

Step by Step

Using timed reminders

Prerequisite: You have saved a reminder → Page 76. The saved time arrives.

Timed reminder at 12.00



or



The phone rings. The appointment time is displayed.

Press key twice.

Lift the handset and replace it again.



If you do not answer the timed reminder, it is repeated five times and then deleted.

Sending a message

You can send short text messages to individual stations or groups of stations with system telephones.

Creating and sending a message



Send message?



Open the idle menu → Page 17.

Select and confirm the option shown.

Enter the internal station number of the recipient or group.

0=Please callback?

Select predefined text (can be changed by service personnel) and confirm.



or

Enter the code directly.

The code is shown on your display with the corresponding message.

or

Enter message text?



Select and confirm the option shown.

Text entry (up to 24 characters) → Page 16.

Send?

Confirm the option shown.



Transmitted text messages are saved as callback requests on system telephones with no display and on ISDN, pulse or tone dialing telephones.

Step by Step



Sent messages?

Text?

Delete?



or

View messages?↕

Text?

When?

Call sender?

Delete?

Displaying and deleting messages you have sent

Prerequisite: The recipient has not yet accepted a sent message.
Open the idle menu → Page 17.

Select and confirm the option shown.

Confirm the option shown.

The text message is displayed.

Select and confirm the option shown.

The message is deleted.

Viewing and editing incoming messages

Pay attention to the notes on → Page 18.

The LED lights up. Press the key shown.

Confirm the option shown.

The sender's caller ID appears on the display.

Confirm the option shown.

The text message appears on the display.

Viewing the transmission time

Confirm the option shown.

Calling the sender

Select and confirm the option shown.

Deleting messages

Select and confirm the option shown.

Step by Step

Leaving an advisory message

You can leave messages/advisory messages on your phone's display for internal callers that wish to contact you in your absence. When you receive a call, the message appears on the caller's display.



Open the idle menu → Page 17.

Advisory msg. on?

Select and confirm the option shown.

0=Back by:

Select predefined text (can be changed by service personnel) and confirm.

or



Enter the code directly.

The code is shown on your display with the corresponding message.



Predefined messages with a colon can be completed by entering a digit.

or

Enter message text?

Select and confirm the option shown.



Enter message (up to 24 characters) → Page 16.

Save?

Confirm the option shown.



Open the idle menu → Page 17.

Advisory msg. off?

Select and confirm the option shown.

Deleting advisory messages

Step by Step

Displaying the number of waiting calls/ overload display

You can show the number of external waiting calls on the display if you programmed the "View number of calls" key → Page 59.



Press the " Calls in Q" key.

If the number of waiting calls exceeds a preset limit while you are engaged in another call (overload), the LED on the key lights up. Contact your service personnel to find out the waiting call limit.

- LED off: There are no waiting calls.
- LED is flashing slowly: The set limit has been reached.
- LED is flashing quickly: The limit has been exceeded (overload).

Using another telephone like your own for a call

Other parties can temporarily use your phone like their own for an outgoing call.



Press the key shown.

PIN and Authorization?↕

Select and confirm the option shown.

***508=Temporary Phone?**

Select and confirm the option shown¹.



Enter the number of the other user.



Enter the other user's lock code → Page 75.

if nec.

Change code?

If the other user has not set a PIN, he or she is prompted to do so on his or her phone.



Dial the external number.

This state is canceled as soon as the call is ended.

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Change number (exchanged phone/ move/relocate)

When configured (consult your service personnel), you can move your number to any other phone.

Your present phone is then assigned with the old number of your new phone. The number and settings of the phone (e. g. programmed keys) are exchanged.

Prerequisite: Your old and new telephone are the first telephones at each connection. The telephones are in idle state.

The following procedure is carried out on the new phone.



Press the key shown.

Relocate?

Select and confirm the option shown.



Enter own station number.



Enter code (telephone lock → Page 75).
(Not necessary if you have not set a code.)

Complete relocate?

Confirm the option shown.



If you change numbers of different system phones, programmed keys are replaced with the default assignment. You can however connect your phone to a different port and then carry out the procedure.

Fax details and message on answering machine

If a fax or answering machine is connected to your system and you have assigned the "Fax details" function to a programmable key → Page 59, the key lights up when a fax or a message has been received.

Deactivating signaling



Press the flashing key "Fax service". The LED goes out.

Step by Step

Resetting services and functions (system-wide cancellation for a telephone)

A general reset procedure is available for initiated functions. The following functions are deleted, if enabled:

- Forwarding on
- Advisory msg. on
- Ringing group on
- Hunt group off
- Suppress call ID
- Call waiting tone off
- Do not disturb on
- Ringer cutoff on
- Received messages:
- View callbacks



Press the key shown.

#0=Resetting services?

Select and confirm the option shown¹.

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Activating functions for another telephone

If configured (contact your service personnel), you can activate and deactivate the following functions for other phones (associated service):

- Do not disturb,
code: *97/#97 → Page 70
- Call forwarding, code *11, *12, *13/#1 → Page 29
- Lock and unlock phone,
code *66/#66 → Page 73
- Ringing group
code *81/#81 → Page 99
- Leave an advisory message,
code *69/#69 → Page 79
- Group call,
code *85/#85 → Page 99
- Reset services and functions,
code #0 → Page 82
- Control relays,
code *90/#90 → Page 88
- Night answer,
code *44/#44 → Page 58
- Timed reminders,
code *46/#46 → Page 76



Press the key shown.

***83=Associated services?**

Confirm the option shown.



Enter the internal station number of the phone where you wish to activate the function.



Enter code (for example, *97 for "Do not disturb on").

For any additional input, follow the instructions on your display.

Step by Step

Using system functions from outside DISA (direct inward system access)

If configured (contact your service personnel), you can use an external phone like an internal station to set up an outgoing external connection via the system. You can also activate or deactivate the following system functions:

- Reset services and functions, code #0 → Page 82
- Call forwarding, code *1/#1 → Page 29
- Lock and unlock phone, code *66/#66 → Page 73
- Save your PIN, code *93 → Page 75
- Send a message, code *68/#68 → Page 77
- Leave an advisory message, code *69/#69 → Page 79
- Ringing group, code *81/#81 → Page 99
- Group call, code *85/#85 → Page 99
- Caller ID suppression, code *86/#86 → Page 71
- Camp-on tone, code *87/#87 → Page 48
- Open door, code *61 → Page 36
- Release door opener, code *89/#89 → Page 37
- Control relays, code *90/#90 → Page 88
- Do not disturb, code *97/#97 → Page 70
- Ringer cutoff, code *98/#98 → Page 69
- Dial using speed dial, code *7 → Page 43
- Associated service, code *83 → Page 83

Prerequisite: Your phone supports tone dialing (DTMF) or you can switch your phone to tone dialing. The phone is not connected to the system.



Establish a connection to the system. Enter the station number (contact your service personnel).

Step by Step



Wait for the continuous tone (if necessary, switch phone to tone dialing) and enter the internal number assigned to you and the corresponding PIN.



Enter the code (only required if programmed in the system).



Wait for the dial tone and enter the code for example, *97 for Do not disturb on. If necessary, make further entries; refer also to the user guide for dial pulse/DTMF phones.

or



Dial the external number.



You can only perform one function/establish one outgoing connection at a time.
The connection is cleared as soon as the function is successfully activated.
In the case of an external call, the connection is cleared as soon as one of the call partners hangs up.

Using functions in ISDN via code dialing (keypad dialing)

If authorized (contact your service personnel), you can access ISDN functions in some regions using codes.



Press the key shown.

***503=Keypad dialing?**

Confirm the option shown.



Enter the required trunk number (contact your service personnel).



Entering a code for required ISDN function (contact your service personnel).



Contact your network provider to find out which ISDN functions can be code-operated in your country.

Deutsche Telekom shall not be liable for damages/costs which may be incurred by fraudulent activities or remote operation (such as toll fraud).

Step by Step

Controlling connected computers/programs/telephone data service

If this function has been configured (contact your service personnel), you can control connected computers or programs running on them, such as hotel services or information systems, from your telephone.

Prerequisite: You have set up a connection.



Press the key shown.

*42=Tel. data service?

Confirm the option shown.

For entering data, you are guided by the connected computer. However, depending on configuration (contact your service personnel), you must activate your entries in one of the following ways:

Inputs in en-bloc mode:



Enter data.



Complete entry.

or

Entry complete?

Confirm the option shown.

or

Inputs in online mode:

The connected computer processes your entries directly.



Enter the code.



Enter data.

Step by Step

Communicating with PC applications over a CSTA interface


If configured (contact your service personnel), you can use your phone to communicate with PC applications (CSTA = Computer Supported Telecommunications Applications). You send information to the application and receive information from the application, for example, via your phone display.



Enter the code.



Enter the three-digit ID for the application you wish to control.



Use the relevant keys to communicate with the application.

Temporarily interrupting communication with the application



The phone is ringing. You answer the call.



The "Data I/O" key flashes: Communication to the application is automatically interrupted.

Resuming communication with the application



Press the flashing "Data I/O" key. The LED lights up.

Ending communication with the application



Select and confirm the relevant CSTA message.

or



Lift the handset and replace it again.

Step by Step

Controlling relays

If this function has been configured (contact your service personnel), you can use up to four relays to enable/disable different devices (such as a door opener).

Depending on how you program the relays, you can activate and deactivate them manually them or configure them to activate and deactivate automatically (after timeout).



Special features must be taken into consideration if your telephone operates with IP-Netpackage (system networking via PC network) → Page 108!

***90=Control relay on?**

or

#90=Control relay off?

Select and confirm the option shown.

select and confirm the option shown



Enter the relay.

Sensors (Octopus F200/F400 only)

If configured (contact your service personnel), sensors are able to recognize signals, call your phone, and display an appropriate message on the screen.

Step by Step

Paging persons

If radio paging equipment (PSE) is connected to your system (contact your service personnel), you can locate people via their pocket receivers.

Pocket receivers signal a call request to the person you want to page. This person can then answer the page at the nearest phone.

Paging persons

To ensure that you can be found, you must have enabled a ringing group → Page 101, call forwarding → Page 29 or call forwarding-no answer (service technician) to the internal station number of your PSE.

A call request is signaled automatically.

Answering the page from the nearest telephone



Lift the handset.



Enter the code.



Enter own station number.

Step by Step

Making calls in the team/executive/secretary configuration

If configured (consult your service personnel), you belong to a team of subscribers with multiple lines (multi-line → Page 11). Your phone features trunk keys (MULAP keys) → Page 91.

Lines

A distinction is made between primary and secondary lines. Each of these line types can be used on a private or shared basis → Page 90.

Primary line

All multi-line telephones have a primary line. This line can be reached in the usual manner via your public phone number. Incoming calls are signaled on this line.

Secondary line

The secondary line on your phone is used as a primary line by another subscriber. Your primary line, which is configured on another telephone, simultaneously functions as the secondary line on that telephone.

Line utilization

Private line

A line that is used by a single telephone. This line cannot be used as a secondary line by another telephone.

Shared line

A line that is configured on multiple telephones. The line status (if configured) is displayed for all telephones that share this line. If, for example, a shared line is being used by a telephone, a status message indicating that this line is busy is displayed on all other telephones.

Direct call line

A line with a direct connection to another telephone. You can see the status of the line from the LED.

Line seizure

Line seizure must be configured (consult your service personnel). If automatic line seizure is configured, a trunk is automatically assigned when you lift the handset or press the trunk key.

Step by Step

Trunk keys




The programmable sensor keys on multi-line phones function as trunk keys. Every sensor key programmed as a "Trunk key" (key label: Transfer Trk) corresponds to a trunk with the result that you can configure up to eight trunks in Octophon F615 TDM.

As a team member, you can independently program the following functions on sensor keys → Page 59:

- Direct station select
- Join/leave group
(not available on executive phone in an executive/secretary team)
- Ring Transfer: On/Off
(only in an executive/secretary team)

You can also program a sensor key with the function "Forward Line" (call forwarding) for each line.


LED displays on trunk keys

LED		Explanation
	Off	- The line is in idle mode.
	Flashing ¹	- Incoming call on the line - Hold reminder is activated - The line is on "Hold".
	On	- The line is busy.

[1] In this manual, flashing sensor keys are identified by this icon, regardless of the flashing interval. The flashing interval represents different statuses, which are described in detail in the corresponding sections of the manual.

Step by Step

Answering calls with the trunk keys

if nec. 

Prerequisite: Your telephone rings or the trunk key flashes quickly.

Press the trunk key that is flashing quickly.
(not necessary if "Prime Line" is active).



Lift the handset.

or

On-hook dialing: Speakerphone mode.

Dialing with trunk keys

if nec. 

Press the free trunk key you wish to use to establish the connection
(not necessary if "Prime Line" is active).



Dial the phone number.



If the party does not answer: Lift the handset.

or

On-hook dialing: Speakerphone mode.

Placing a call on hold on a trunk key and retrieving the held call


Prerequisite: You are conducting a call via one of your group's trunks.
The "Hold" key has been programmed on your telephone
→ Page 59.

Hold



Press the "Hold" key.

if nec.



Replace the handset or press the disconnect key.

Depending on the configuration (contact your service personnel),
this may be necessary so other team members can also pick up the
call on hold.



Retrieving the call

Press the trunk key flashing slowly.

Step by Step

Making calls on multiple lines alternately

Prerequisite: You are conducting a call via one of your group's trunks. Another trunk key is flashing.



Press the flashing trunk key. The first call party is on hold on the other trunk.



Press the trunk key flashing slowly. The second call party is on hold.

You can switch between lines as often as you wish. Press the trunk key flashing slowly each time.

MULAP conference release

If configured (consult your service personnel), you can program a sensor key on your phone with the function "MULAP Privacy Release" → Page 59. The default label is "Priv Release".

If you program this key, you do not have to use the menu to set up a conference. Your team partner only has to press the flashing trunk key associated with your trunk on his or her phone to immediately join the conference.



You are conducting a call.



Press the "Priv Release" key. The LED lights up.

Up to three team members can now join the conference.

Prerequisite: The trunk on which you are speaking is configured on the other phone as a trunk key.



Press the flashing trunk key.

Step by Step

Direct station selection key

Each team member has a direct station selection key for every other team member.

This means that each team member can be reached directly by other team members at the touch of a button.

Understanding LED messages from DSS keys



LED on the DSS key is off - the team member is not engaged in a phone call.

or



LED on the DSS key is lit - the team member is engaged in a phone call or has activated do not disturb.

or



LED on the DSS key is flashing **rapidly** - a call has arrived for you and needs to be answered.


or



LED on the DSS keys is flashing **slowly** - a caller is trying to reach another member of your team, who has not yet answered.

Using DSS keys to answer calls

Prerequisite: Your telephone rings or the DSS key flashes.



Press the flashing DSS key.

This is not necessary if you are called directly (DSS key flashes quickly).



Lift the handset.

or

On-hook dialing: Speakerphone mode.

Calling a team member directly



Press the DSS key.

or



If the team member you wish to reach is engaged in another call, the DSS key on your telephone is lit. You can still make the call in this case.



If the party does not answer: Lift the handset.

or

On-hook dialing: Speakerphone mode.

Step by Step

Transferring a call in progress



Press the DSS key and announce the call if necessary.



Replace the handset.

or



Press the key shown.

Accepting a call for another team member



Press the flashing DSS key or trunk key.



Lift the handset.

or

On-hook dialing: Speakerphone mode.

Step by Step

Forwarding calls on trunks

You can immediately forward internal or external calls to different internal or external telephones (destinations). (External destinations require special configuration in the system).

Activating call forwarding for one trunk activates the function for all trunk keys assigned to this trunk in your group.



Open the Program/Service menu → Page 20.

Forward Line: On

Select and confirm the option shown.

or



If available, press the "CFW MULAP" key.
(You have programmed a key with the incomplete "CFW MULAP" function, excluding the call forwarding type and destination → Page 59.)



Press the required trunk key.

or



Enter the required trunk number.

1=all calls

Select and confirm the option shown,

or

2=external calls only

select and confirm the option shown,

or

3=internal calls only

select and confirm the option shown.



Enter the destination number.

Save

Confirm.

or



If available, press the "CFW MULAP" key. (You have stored the call forwarding type and destination on the "CFW MULAP" key, → Page 59.)

Step by Step

Forward Line: Off



Open the Program/Service menu → Page 20.

Select and confirm the option shown.



Press the required trunk key.

or



Enter the required trunk number.

or



If available, press the "CFW MULAP" key.



If you have activated call forwarding for a trunk, a special dial tone sounds when the line is seized.

Understanding LED messages of the "CFW MULAP" key



The LED on the "CFW MULAP" key is off - call forwarding is not active for this trunk.

or



The LED on the "CFW MULAP" key lights up - call forwarding is active for this trunk.

or



The LED on the "CFW MULAP" key flashes **slowly** - the trunk is the destination of call forwarding.

Step by Step

Transferring calls directly to the executive phone

Normally, all calls for the executive are audibly signaled only by the secretary phone.

You can set audible signaling so calls are signaled only by the executive phone or by a second phone assigned to it.

Prerequisite: On your phone there is a sensor key programmed with the function "Ring Transfer". The default label is "Ring xfer".

Activating



Press the "Ring xfer" key. The LED lights up.

or



Open the Program/Service menu → Page 20.

Ring Transfer: On

Select and confirm the option shown.



Press the required trunk key.

or



Enter the required trunk number.

Deactivating



Press the "Ring xfer" key. The LED goes out.

or



Open the Program/Service menu → Page 20.

Ring Transfer: Off

Select and confirm the option shown.



Press the required trunk key.

or



Enter the required trunk number.

Step by Step

Using team functions

If configured (consult your service personnel), your telephone is part of a team. The team consists of internal phones that are able to use certain functions.

Activating/deactivating a group call



Special features must be taken into consideration if your telephone operates with IP-Netpackage (system networking via PC network) → Page 104!

If configured (consult your service personnel), you belong to one or more groups of stations, which can be reached via hunt group or group call station numbers.

Incoming calls are signaled one after the other (= hunt group) or simultaneously (= group call) on all phones in the group, until a group member answers the call.

You can also belong to a team (including executive/secretary configurations) in which station numbers are programmed on trunk keys → Page 90.

Each station in the group can still be reached via their personal station number.

You can activate and deactivate the audible signal for a hunt group, group call or individual trunks in a group (including executive/secretary).

If the LED on a programmed "Hunt group" key is illuminated → Page 59, this means that the audible tone was activated for at least one group.



This function is not available for the executive phone in team/executive/secretary configurations.

You are part of a hunt group or call group



Open the idle menu → Page 17.


Group call off?

Select and confirm the option shown¹,

or

Group call on?

select and confirm the option shown



Press the "Hunt group".

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

You belong to multiple groups



Open the idle menu → Page 17.

Group call off?

Select and confirm the option shown^[1],

or

Group call on?

select and confirm the option shown



Press the "Hunt group".

301 X Group name

If an "X" appears between group/trunk number (such as 301) and group name, the audible tone is active for this group or trunk.

or

301 Group name

No "X" means that the audible tone is deactivated.

Next?

Confirm the option shown. The next group/trunk number is displayed with a group name.

or

Group call off?

Select and confirm the option shown¹.
The audible tone for the group/trunk displayed is deactivated.

or

Group call on?

Select and confirm the option shown^[1].
The audible tone for the group/trunk displayed is activated.

or

#=Leave all groups?

Select and confirm the option shown.
The audible tone for all groups and trunks is deactivated.

or

*=Rejoin all groups?

Select and confirm the option shown.
The audible tone for all groups and trunks is activated.



If you have activated the audible tone for another group/trunk or deactivated the audible tone for all groups/trunks you belong to, you will hear a special dial tone when you lift the handset.

[1] "Differing display view in a Octopus F900 environment" → Page 114

Step by Step

Accepting a call for another member of your team

You can use your own telephone to accept calls for other telephones in your team, even while on a call (call pickup groups; contact your service personnel).

Prerequisite: Your telephone rings briefly. "Call for:" appears on the upper display line with the number or name of the originator. The number or name of the caller appears on the lower line.

Confirm the option shown.

Pickup - group?

Ringing group

You can have calls for your telephone signaled audibly at up to five other internal phones. The phone that answers the call first receives the call.



Special features must be taken into consideration if your telephone operates with IP-Netpackage (system networking via PC network) → Page 107!

Saving, displaying, and deleting telephones for the ringing group

Press the key shown.



*81=Ringing group on?

Select and confirm the option shown.

Follow the display prompts (enter the internal station number).



If your phone belongs to a ringing group, your display will show the station number or the name of the originator on the upper line and that of the caller on the lower line.

Removing all telephones in a call ringing group

Select and confirm the option shown.

Ringing group off?

Step by Step

Uniform Call Distribution (UCD)

If configured (consult your service personnel), you may belong to a group of stations (agents), to which calls are distributed. An incoming call is always assigned to the agent idle the longest.

Logging on and off at the beginning and end of your shift



Press the key shown.

UCD?

Select and confirm the option shown.

*401=Log on?

Confirm,

or

#401=Log off?

select and confirm the option shown



To log on, enter your identification number ("Agent:"). Contact your service personnel to find out what it is.

Logging on and off during your shift



Press the key shown.

UCD?◆

Select and confirm the option shown.

#402=Not available?

Confirm the option shown.

or

*402=Available?

select and confirm the option shown

Step by Step

Requesting and activating a work time

You can request/activate work time to ensure you have enough time to wrap up the last call. Your phone is excluded from call distribution for a set period or until you log back on.



Press the key shown.

UCD?

Select and confirm the option shown.

*403=Work on?

Confirm the option shown.

or

#403=Work off?

select and confirm the option shown

Turning the night service on and off for UCD



Press the key shown.

UCD?

Select and confirm the option shown.

*404=UCD night on?

Confirm the option shown.

or

#404=UCD night off?

select and confirm the option shown

Display the number of waiting calls



Press the key shown.

UCD?

Select and confirm the option shown.

*405=Calls in queue?

Confirm the option shown.

Step by Step

Special functions in the LAN

If your telephone is operating in a IP-Netpackage environment, multiple Octopus F100/200/400/650 systems are interconnected via a LAN (Local Area Network, e. g. proprietary PC network). You are conducting a call via the LAN (PC network).

In this instance, you must note certain particularities for some functions. These are described in this section.

Leaving hunt group/group call

Prerequisite: You are part of a hunt group/group call → Page 99 in another Octopus F100/200/400/650:



Open the idle menu → Page 17.

Internal DISA?

Select and confirm the option shown.



Enter the (DISA) call number of the other Octopus F100/200/400/650.

OK or

Confirm your entry.



Enter the (DISA) station number of your phone.

OK or

Confirm your entry.

Group call off?

Select and confirm the option shown.

or

Group call on?

select and confirm the option shown

You belong to multiple groups associated with another Octopus F100/200/400/650



Enter group number for "directed joining/leaving".

Step by Step

Setting up "follow me" call forwarding

You can activate/deactivate call forwarding IP-Netpackage for your phone from other phones in the → Page 29 environment.



Open the idle menu → Page 17.

Internal DISA?

Select and confirm the option shown.



(DISA) station number of the Octopus F100/200/400/650.

OK or #

Confirm your entry.



Enter the (DISA) station number of your phone.

OK or #

Confirm your entry.

Activating



Open the idle menu → Page 17.

Forwarding on?

Select and confirm the option shown.

1=all calls?

Confirm,

or

2=external calls only?

select and confirm the option shown,

or

3=internal calls only?

select and confirm the option shown



Enter the destination phone number.

Save?

Confirm the option shown.

Deactivating



Open the idle menu → Page 17.

Forwarding off?

Select and confirm the option shown.

Step by Step

Using night answer

If authorized (contact your service personnel), you can define telephones in other Octopus F100/200/400/650 communications platforms as the night answer → Page 58.



Open the idle menu → Page 17.

Internal DISA?

Select and confirm the option shown.



Enter the (DISA) call number of the other Octopus F100/200/400/650.

OK or #

Confirm your entry.



Enter the (DISA) station number of your phone.

OK or #

Confirm your entry.

Activating



Open the idle menu → Page 17.

Night answer on?

Select and confirm the option shown.



Enter the destination number (= temporary night answer service).

Save?

Confirm the option shown.

Deactivating



Open the idle menu → Page 17.

Night answer off?

Select and confirm the option shown.

Step by Step

Ringling group

You can have calls for your telephone signaled audibly at external telephones or at telephones in other Octopus F100/200/400/650 communications platforms → Page 101.

Saving, displaying, and deleting telephones for the ringing group



Press the key shown.

*81=Ringling group on?

Select and confirm the option shown.

Add to ringling group?

Select and confirm the option shown.

or

Add another station?

select and confirm the option shown,

or

View/delete?

select and confirm, then follow the operating instructions.



Enter the station number.

#=Entry complete?

Confirm the option shown.

Save?

Confirm the option shown.

End?

Select and confirm the option shown.

Removing all telephones in a call ringling group



Open the idle menu → Page 17.

Ringling group off?

Select and confirm the option shown.

Step by Step

Controlling relays (only for Octopus F100/200/400/650)

If this feature is configured (contact your service personnel), you can also control relays → Page 88 in other Octopus F100/200/400/650 communications platforms.



Open the idle menu → Page 17.

Internal DISA?

Select and confirm the option shown.



Enter the (DISA) station number of the Octopus F100/200/400/650 where you wish to control the relay.

OK or #

Confirm your entry.



Enter the (DISA) station number of the phone you wish to use to control the relay.

OK or #

Confirm your entry.

*90=Control relay on?

Confirm,

or

#90=Control relay off?

select and confirm the option shown

1 ... 4ghi

Enter the relay.

Step by Step

Opening a door

If this feature is configured (contact your service personnel), you can also activate the door opener → Page 36 in other Octopus F100/200/400/650 communications platforms.

Open the idle menu → Page 17.

Select and confirm the option shown.

Enter the (DISA) station number of the Octopus F100/200/400/650 where you wish to control the door opener.

Confirm your entry.

Enter the (DISA) station number of the phone you wish to use to control the door opener.

Confirm your entry.

Select and confirm the option shown.

Dial the entrance telephone number.



Internal DISA?



OK

or

#



OK

or

#

Door opener?



Step by Step

Individual phone configuration

Setting contrast

The display has four contrast levels that you can set according to your light conditions.

or

Press one of the keys shown in idle mode.

Display contrast?

Select and confirm the option shown.

or

Change the display contrast. Press the key repeatedly until the desired level is obtained.

Save.

Adjusting audio settings

Optimize the audio settings on your Octophon F615 TDM for your work environment and according to your personal requirements.

Adjusting the receiving volume during a call

You are conducting a call.

or

Raise or lower the volume. Keep pressing the key until the desired volume is set.

Save.

Adjusting the ring volume

or

Press one of the keys shown in idle mode → Page 17.

Ring volume?

Confirm the option shown.

or

Raise or lower the volume. Keep pressing the key until the desired volume is set.

Save.

Step by Step

or

Adjusting the ring tone

Press one of the keys shown in idle mode → Page 17.

Ring tone?

Select and confirm the option shown.

or

To adjust the ring tone: Keep pressing the keys until the desired tone is set.

Save.

Adjusting the attention ring volume

If you are part of a team with trunk keys, other calls can be signaled acoustically in the team during a call. You will hear the attention ring.

or

Press one of the keys shown in idle mode → Page 17.

Attention Ring Vol.

Select and confirm the option shown.

or

Raise or lower the volume. Keep pressing the key until the desired volume is set.

Save.

Adjusting the speakerphone to the room acoustics

To help the other party understand you clearly while you are talking into the microphone, you can adjust the telephone to the acoustics in your environment: "Quiet room," "Normal room" and "Noisy room."

or

Press one of the keys shown in idle mode → Page 17.

Speakerphone mode?

Select and confirm the option shown.

or

To set the room type: Keep pressing these keys until the setting you want appears on the screen.

Save.

Step by Step



Activating/deactivating the ringer

Hold down the key shown.



Language for system functions

Press the key shown.

more functions?↕

Select and confirm the option shown.

***48= Select language?**

Select and confirm the option shown.

15=Spanish?

Select the language you wish to use (e. g. "Spanish") and press the "OK" dialog key to confirm.

Step by Step

Testing the phone

Phone functions, testing

You can test your phone's functionality.

Prerequisite: The phone is in idle mode.



Press the key shown.

more functions?↕

Select and confirm the option shown.

*940=Phone test?

Select and confirm the option shown.

If everything is functioning correctly:

- all LEDs on the phone flash (only the menu key LED is continuously lit)
- your station number is displayed
- the ring tone is audible

Checking the key assignment

You can check key assignment on your phone to determine which functions are assigned to which keys.



Open the Program/Service menu → Page 20.

Prog. feature key

Select and confirm the option shown.



Press any key. The key assignment is displayed.

Exit

Select and confirm the option shown.

Step by Step

Differing display view in a Octopus F900 environment

Depending on the system configuration, some functions may not always be offered in the display as described in this document.

In addition, display texts may differ from those described in this document according to the system configuration.

The following table provides an overview:

Octopus F270 IT/100/200/400/650 display	Octopus F900 display	Description
Service	Service menu?	→ Page 20
Transfer	Transfer?	→ Page 28
View callbacks	Show callback destinations?	→ Page 33
Pickup - directed	Directed pickup	→ Page 34
Caller list	Call log?	→ Page 39
Use speed dialing	Use speed dialing?	→ Page 43
Change speed dial	Speed dial?	
Call waiting term.	Second call release?	→ Page 48
Call wait.trm. on/off	Second call on/off?	
Silent on/off	Ringer cutoff on/off?	→ Page 69
Group call on/off	Hunt group on/off?	→ Page 99

Step by step

Invalid entry

Not authorized

Currently not possible

Invalid station number

Fixing problems

Responding to error messages

Possible causes:

Station number is incorrect.

Possible reactions:

Enter correct station number.

Possible causes:

Locked function selected.

Possible reactions:

Apply to service personnel for authorization for relevant function.

Possible causes:

Dialed a non-existent station number. Called phone is unplugged.

Possible reactions:

Enter correct station number. Call this station again later.

Possible causes:

Dialed your own station number.

Possible reactions:

Enter correct station number.

Contact partner in the case of problems

Contact your service personnel if a fault persists for more than five minutes, for example.

Step by step

Troubleshooting

Pressed key does not respond:

Check if the key is stuck.

Telephone does not ring:

Check whether the "Do not disturb" function is activated on your telephone (→ Seite 70). If so, deactivate it.

You cannot dial an external number:

Check whether your telephone is locked.
If the phone is locked, enter your PIN to unlock it → Seite 73.

To correct any other problems:

First contact the relevant service personnel. If the service personnel are unable to correct the problem, they must contact Customer Service.

Caring for your telephone

- Never allow the telephone to come into contact with coloring, oily or aggressive agents.
- Always use a damp or antistatic cloth to clean the telephone. Never use a dry cloth.
- If the telephone is very dirty, clean it with a diluted neutral cleaner containing surfactants, such as a dish detergent. Afterwards remove all traces of the cleaner with a damp cloth (using water only).
- Never use aggressive or alcohol-based cleansers on plastic parts. The use of scouring agents is also forbidden.

Labeling keys

You can choose from the following options to label the keys with the functions/call numbers saved (, → page 59):

Labeling

- by hand:
Labeling strips are delivered with your Octophon F615 and key module for Octophon F615. Write the function or a name on the matching strips within the white field and attach them to your Octophon.
- with a computer:
You have available a CD Rom (ask your service personnel) with the electronic operating instructions for your → page 3. You can label your keypads for each PC.

Put the labeled strips in the relevant key pad on your Octophon and place the transparent cover over them (mat page above).

Index

A

Accept (Call)	34, 101
Account code	68
Activating door opener	36
Advisory message	79
deleting	79
Agents	102
Alternate	27
Announcement	44
Answering machine	81
call pickup	37
Assigning DID number	46
Associated dialing/dialing aid	46
Associated service	83
Attention ring volume	111
Audio keys	14
Automatic call waiting	
preventing and allowing	48
Automatic connection setup	45
Automatic line seizure	24

B

Busy override	57, 71
---------------------	--------

C

Call	
accepting	21
accepting from the answering	
machine	37
accepting in a team	95
accepting, directed	34
accepting, group	101
answering	21
distributing	102
entrance telephone	36
forwarding	29
forwarding in a team	96
forwarding MSN in CO	31
holding	50
in a team with trunk keys	92

parking	49
rejecting	26
retrieving from park	49, 50
transfer after announcement	55
transferring	28
transferring	95
using DSS keys in a team	94
Call charge assignment	68
Call charges	
for another phone	66
for your phone	66
Call duration	66
Call forwarding	29
MSN in CO	31
Call log	19
Call request	19
Call signal	21
Call volume	21, 110
Call waiting	57
accepting	47
tone off	48
Call waiting tone on/off	48
Callback	32
Caller ID suppression	71
Caller list, using	39
Calling a second party	27
Calls	
recording	54
Calls in queue	80, 102
CE marking	2
Central speed dial	43
Central telephone lock	74
CFNR	30
Change number	81
Charges	
for another phone	66
for your phone	66
Checking the key assignment	113
Code dialing in ISDN	85
Conference	27
Connection setup	
automatic	45
Consultation	27
Control relays	88
CSTA	87

D

Details, fax	81
Dial	
with en-bloc dialing	38
Dialing	
from the caller list	39
from the internal directory	40
internal/external calls	24
on-hook dialing	24
using DDS keys	24
using redial	25
using speed dial	43
with the dialing aid	46
Dialing aid	
S0 bus	46
Dialing internal calls	24
Differences	11
Direct Inward System Access	84
Direct station select	60, 94
DISA	84
Discreet calling	45
Display contrast	110
Display view for	
Octopus F900 environment	114
Distributing calls	102
Do not disturb	70
Door release	37
DTMF suffix dialing (tone dialing)	53

E

Editing a dialed number	38
Editing number	38
En-bloc dialing	38
Entrance telephone	36
Exchanged phone	81
External code	24

F

Fax details	81
Forwarding	29
multiple subscriber numbers (MSN)	31
Forwarding MSN in CO	31
Forwarding multiple subscriber numbers (MSN) ..	31
Function key	
programmable	15
Functions	
for another phone on/off	83
programming a key	59
resetting	82
using from the outside	84

G

General information	10
Group call	99

H

Handsfree answerback	35
off	35
on	35
Hold	50
Hotline	45
Hotline delayed	45
Hunt group	99

I

Important information	3
Incoming calls	19
Individual speed dial	43
Internal directory	40
IP telephony	104
IP-Netpackage	
"follow me" call forwarding	105
group call	104
hunt group	104
night answer	106
opening a door	109
relays	108
ringing group	107

K

key module for Octophon F615 13

Key modules 13

Keypad 16

Keypad dialing 85

Keys

- programming 59
- save incomplete 59

L

LAN telephony 104

LDAP directory 41

LDAP directory Dialing

- from the LDAP database 41

Leaving an advisory message 79

LED

- trunk keys 91

LED display

- direct station selection keys 15
- function keys 15

LED messages, understanding 60, 94, 97

Line seizure, automatic 24

Line utilization 90

Location of the telephone 3

Locking/unlocking 73

Loudspeaker 22

M

Mailbox key 12, 14

Making external calls 24

Making mobile calls 80

Making trunk calls 24

Menu key 12, 14

Message

- answering 78
- receiving 78

Message(text)

- deleting/viewing 77
- sending 77

Move function 81

Moving with the phone 81

MULAP conference release 93

MULAP keys, trunk keys 90

Multi-line telephone 11

N

Name plate 11

Navigation keys 14

Night answer 58

Number

- assigning 46
- correcting 38
- deactivating display 71
- saving 64
- suppressing 71

O

Open door 36

Open listening 23

Opening a door

- with a code 36

Operating instructions 2

Operating steps

- programming a key 62

Operational elements 12

Outgoing calls 19

Overload 80

P

Parking a call 49

Personal identification number 75

Phone

- locking another phone 74
- locking/unlocking centrally 74
- testing 113
- using another phone like your own 80

Phone functions, testing 113

Phone settings 110

PIN 75

- for a telephone 73

PIN, saving 75

Placing a call on hold

- in the team 92

Primary line 90

Private line 90

Procedure

- programming a key 62

Product designation 11

Product variants 11

- Program/Service menu 20
 Programmable function key 15
 Programming free keys 59
 Programming your telephone 110
 Project calls 68
- R**
- Radio paging equipment (PSE) 89
 Recall 55
 Receiving volume 21, 110
 Recording 54
 Redialing a number 25
 from the caller list 39
 Relays 88
 Relocate 81
 Reserve trunk 45
 Resetting functions 82
 Resetting services 82
 Ring tone 111
 Ring transfer
 in an executive/secretary team 98
 Ring volume 110
 Ringer cutoff 69
 Ringing group 101
 Room monitor 72
- S**
- Safety precautions 2
 Second call
 accepting 47
 allowing 48
 preventing 48
 Second level 24
 Secondary line 90
 Secret busy override 71
 Sensors 88
 Serial number 11
 Settings 110
 Settings on your telephone 110
 Shared line 90
 Shift 24
 Shift key 24
 Silent Monitoring
 tone off 71
 Single-line telephone 11
 Speaker call 44
 Speakerphone mode 22, 23
 function 23
 information 3, 11, 22
 set room character 111
 setting the volume 111
 Special dial tone 70
 Speed dial
 central 43
 dialing 43
 save individually 43
 Speed-dialing
 suffix-dialing 43
 Suffix-dialing
 automatic 43
 DTMF tone dialing 53
 System-wide cancellation 82
- T**
- Tel. data service 86
 Telephone
 locking 73
 locking/unlocking 73
 settings 110
 Telephone lock
 central 74
 Telephone maintenance 116
 Telephone test 113
 Temporary Phone 80
 Testing the telephone 113
 Text
 answering 78
 receiving 78
 Three-party conference 27
 Timed reminder 76
 Timed reminder, answering 77
 Toggle/Connect
 in the team 93
 Tone dialing 53
 Trace call 72
 Transfer (call) 28, 95
 after announcement 55
 Troubleshooting 116
 Trunk flash 56
 Trunk keys 91
 Trunk, reserving 45

U

UCD	102
Unanswered calls	19
User support	10

V






Variable call forwarding	29
Volume	
keys	14

W






Waiting calls	80
Work time	103






Overview of functions and codes

The following table lists all available functions, as shown on the display. If configured (contact your service personnel), functions can be activated interactively (select and confirm) via the Program/Service menu (select and confirm or enter a code).






Functions (=display)	... Interactively	... Via the Program/Service menu	Code
	 	 → Seite 20  	
Accepting call waiting	✓	✓	*55
Call waiting tone off	✓	✓	*87
Call waiting tone on	✓	✓	#87
Call wait.term.on		✓	*490
Call wait.trm.off		✓	#490
Account code		✓	*60
Advisory msg. on	✓	✓	*69
Advisory msg. off	✓	✓	#69
Alternating	✓	✓	*2
Associated dialing		✓	*67
Associated serv.		✓	*83
Busy override	✓	✓	*62
Callback	✓	✓	*58
View callbacks/delete	✓	✓	#58
Caller list	✓	✓	#82
Save number	✓	✓	*82
Conference	✓	✓	*3
Start conference	✓		
Add party	✓		
End conference	✓	✓	#3
View conf parties	✓	✓	
Remove party	✓	✓	
Drop last conf. party			*491
Consultation	✓		
Return to held call	✓	✓	*0
Quit and return	✓	✓	*0
Transfer/Accept call	✓		

Overview of functions and codes

Functions (=display)	... Interactively	... Via the Program/Service menu	Code
	 	 → Seite 20  	
Control Relay On		✓	*90
Control Relay Off		✓	#90
Data I/O Service			*494
DISA			
DISA intern	✓	✓	*47
Discreet calling			*945
Do not disturb on	✓	✓	*97
DND off	✓	✓	#97
Door opener		✓	*61
Door opener on		✓	*89
Door opener off		✓	#89
DTMF dialing		✓	*53
En-bloc dialing			
Dial	✓		
Forwarding on	✓	✓	*1
1=all calls	✓	✓	*11
2=external calls only	✓	✓	*12
3=internal calls only	✓	✓	*13
Forwarding off	✓	✓	#1
CFNR on		✓	*495
CFNR off		✓	#495
Trunk FWD on	✓	✓	*64
Trunk FWD off	✓	✓	#64
HF answerback on	✓	✓	*96
HF answerback off	✓	✓	#96
Hotline			
Join group	✓	✓	*85
Leave group	✓	✓	#85
Rejoin all groups	✓	✓	*85*
Leave all groups	✓	✓	#85#
Keypad dialing		✓	*503
Lock all phones		✓	*943

Functions (=display)	... Interactively	... Via the Program/Service menu  → Seite 20	Code
	 	 	
Lock phone	✓	✓	*66
Unlock phone	✓	✓	#66
Change PIN		✓	*93
Mute on		✓	*52
Mute off		✓	#52
Night answer on	✓	✓	*44
Night answer off	✓	✓	#44
Page			
Answer page		✓	*59
Park a call		✓	*56
Retrieve call		✓	#56
Phone test		✓	*940
Phonebook			
1=internal	✓		*54
2=LDAP	✓		*54
Pickup - directed		✓	*59
Pickup - group	✓	✓	*57
Accept call	✓		
Redial	✓		
Reject calls	✓		
Disconnect			
Relocate	✓	✓	*9419
Complete relocate	✓	✓	#9419
Resetting services		✓	#0
Ringer cutoff on	✓	✓	*98
Ringer cutoff off	✓	✓	#98
Ringling group on		✓	*81
Ringling group off		✓	#81
Room monitor		✓	*88
Select language		✓	*48

Overview of functions and codes

Functions (=display)	... Interactively	... Via the Program/Service menu	Code
	 	 → Seite 20  	
Send message	✓	✓	*68
View sent message	✓	✓	#68
View messages	✓	✓	#68
Mailbox			
Show call charges (own phone)		✓	*65
Silent monitor	✓	✓	*944
Speaker call		✓	*80
Suppress call ID	✓	✓	*86
Restore caller ID	✓	✓	#86
Tel. data service			*42
Temporary MSN	✓	✓	*41
Temporary Phone		✓	*508
Timed reminder on		✓	*46
Timed reminder off		✓	#46
Trace call		✓	*84
Transfer	✓		
Trunk flash)		✓	*51
UCD			
Log on		✓	*401
Log off		✓	#401
Available		✓	*402
Not available		✓	#402
Work on		✓	*403
Work off		✓	#403
UCD night on		✓	*404
UCD night off		✓	#404
Calls in queue		✓	*405
Use speed dialing		✓	*7
Change Speed Dial? (station)		✓	*92

Important telephone numbers

For problems:

For questions regarding sales:

Upon delivery of the equipment, please enter
telephone numbers!

Issued by:
Deutsche Telekom AG

Right of modification reserved.
Reference number: A31003-T9000-U115-1-7619
SW version: 8.0
Status: 12/2009

Printed on environmentally compatible
recycled paper.