


Cell Broadcast Settings Alcatel 3085X


1. Menu/ Messages




2. Klick to OK




3. Klick to Options




4. Select Cell Broadcast list



5. Klick to Options




6. Select Settings



Cell Broadcast Settings Alcatel 3085X

7. Select Channel settings



8. Cell Broadcast Channel settings is shown

