

Brief Description of Functions

Enquiry call



Enter the number

Broker's call



Enter the number

conn1...conn4

Three-party conference call



Enter the number

conf

Call transfer with prior notice



Enter the number

x-fer

Call rerouting



x-fer

Enter the number

Automatic redialing



Enter the number

Subscriber is busy

auto

Deactivating automatic redialing



Automatic dialing

auto

ok

Selecting outgoing MSN



Enter the number


msn

msn1...
msn10


Selection from caller list




Selection from the telephone directory




Selection from speed dialing




Activate call forwarding



Deactivate call forwarding



Station guarding



Information on active functions (Station guarding, call forwarding, call control, dial filter)



Activating / Deactivating call waiting



Connecting a headset

